

NOTES:
1. PARTS MARKED ① USED ON LEFT SIDE ONLY.
PARTS MARKED ② USED ON RIGHT SIDE ONLY.
2. APPLY TAPE SHIELD TO FLEXIBLE CONTROLS & FLEXIBLE TUBES WHERE THERE IS POSSIBILITY OF RUBBING AGAINST ENGINE OR ADJACENT PARTS.
3. NOSE COWL 13716-2 USED WHEN STARTER & GENERATOR ARE NOT INSTALLED ON ENGINE.
4. NOSE COWL 13716 USED WHEN STARTER & GENERATOR ARE INSTALLED ON ENGINE.
5. ▲ = OPTIONAL EQUIPMENT
6. SEAL ALL FIREWALL OPENINGS WITH PLASTIKON RUBBER PUTTY
7. PARTS MARKED "SEE NOTE 7" TO BE USED ONLY WHEN SHIELDED ELECTRICAL SYSTEM IS INSTALLED.
8. IN SHOW UNITS STARTER IS OPTIONAL EQUIPMENT
9. INSTALLATION KIT SENSENICH "M-2-41" (INC. BOLTS, WASHERS, GASKET) SUPPLIED WITH PROPELLER "M2GL"
10. PARTS MARKED ▲ USED ON MODEL PA-18 150" & PA-18A "150 ONLY.
PARTS MARKED △ USED ON MODEL L-21 B MODIFIED (COMPLETE AIRPLANE #14840) ONLY)

	1	14468	1	POWER PLANT
	2	14469	1	COWLING ASSY.
	3	14470	1	ENGINE ASSY.
	4	14471	1	ENGINE ASSY.
	5	14472	1	ENGINE ASSY.